

Vividia® Ablescope® Simple UV Borescopes User Manual
Model: UV-100S



Recommended Software and Apps compatible with UV-100S:

1. **Windows 11/10/8/7/XP:**

Built-in "Camera" App, "Amcap.exe", "Plugable Digital Viewer", "Oasis.exe"

*Download the ones in red at www.oasisscientific.com/downloads.



2. **Android Phones and Tablets:** (Connect with OTG cable) Download from Google Play Store: "USB Camera" (recommended) or "Endoscope Camera" or "MScopes" or "OTG View"

NOTE: Not all Android devices are compatible. Contact us if the connection fails.



3. **MacBook:** Built-in "Photo Booth" App or use "Quick Camera" or "Plugable Digital Viewer" (Recommended)

*Get it from App Store.

** <https://plugable.com/pages/microscope-drivers>



4. **Chromebook:** Built-in "Camera" App.



How to use UV-100S

1. Choose and prepare your display device with the required software.
2. Attach the UV-100S camera via USB and launch the app.
3. View, take photos or videos within the app.
4. Press the handle button switching between **UV lights** and white LED light

Safety Precautions

1. The borescope should be used under 60°C (140°F). High temperature can increase video noise, even damage the camera sensors and electronics.
2. Do not immerse the camera in oils, water, gasoline, or other fluids for a long time >5min.
3. Clean the lens with clean, soft fabric and/or Q-tips with alcohol.
4. Use high quality OTG cable and USB extension cable when needed. And make sure the connection is tight and secure. This will affect the image quality.
5. A phone/tablet case could affect OTG cable connection in some cases. Please remove the case if needed.
6. Avoid moisty environment, temperature shock and extreme temperatures. Dry surroundings help the life of the products.
7. Avoid dropping, violent vibrations, strong collision, or distortion.
8. Keep the device away from chemicals, explosive substances, and fire hazards.

Warranty

One-year limited product quality warranty.

Vividia Technologies

www.vividia-tech.com

2024-05-16
