

## Vividia® FM-113 Desktop Document & Banknote Magnifier



Model: Vividia® FM-113

### Key Features:

Three Types LED lights: UVA-365nm; UVC-254nm; White light

Magnetic Sensor

Magnification ~3×

Two power supply modes: 4×AA Battery (not included in the package) or USB DC 5V

Lightweight: Net ~150g

Medium Size: 19.5\*8.5\*9 cm

### How to use FM-113 magnifier:

1. Install 4 pcs AA batteries as instructed. Or connect a USB power source
2. Put the document under the glass windows on the table
3. Press “Check” button to change the light sources:  
White LED light -- UV 365nm -- UV 254nm -- Off
4. Take out the AA batteries for long term storage



Vividia Technologies

\*\*\*\*\*